PUTTING THE SQUEEZE ON POROUS MATERIALS

P orous materials known as metal-organic frameworks, or MOFs for short, may prove useful to safely store vast quantities of gases, including hydrogen for fuel. They can also be used to separate one gas from a mixture of different gases, and they can be used as catalysts to speed up otherwise sluggish chemical reactions for making agrochemicals, additives, pharmaceuticals, plastics, and other substances. They might even be used in novel drug formulations as highly efficient delivery agents that carry an injected or swallowed medication direct to diseased tissues in the body and release it at a suitable rate. Compression of crystals of synthetic, porous materials by researchers using the APS has revealed new insights into how these materials, with a range of applications, behave under pressure, which could allow scientists to fine tune their properties for industrial, medical, and fuel-storage use.



Fig. 1. Top: Crystal structure of ZIF-8 with a truncated octahedral topology. Particle size and morphology were controlled by varying the concentration of the ligands and Zn(II) precursor. Bottom: TEM images of a 1.2 µm ZIF-8 microcrystal (hexagonal projection) during the *in situ* compression test at various displacements (a) 60, (b) 270, and (c) 480 nm displacement, and (d) after unloading. Adapted from Z. Shu et al., J. Am. Chem. Soc. 137, 1750 (2015). © 2015 American Chemical Society. All rights reserved.

The properties of MOFs are controlled by the different metals and the organic molecules that are used to build their porous, three-dimensional structure. Some MOFs have an internal surface area that can be as high as 7000 square meters per gram of material. However, these materials can be fragile and their mechanical properties are susceptible to failure when they are repeatedly used to store and then release gas, or in reactions where their vast internal surface area allows them to be used as catalysts. Understanding exactly how the stresses and strains in the structure arise when a MOF is put under pressure and then the pressure released is critical to designing new MOFs and to tweaking the structure of known MOFs so that they are stronger.

In a collaboration between the University of Illinois at Urbana-Champaign and Argonne, the effects of pressure applied to single crystals of MOFS were explored. Transmission electron microscopy (TEM) can be used to directly observe the changes that take place when microscopic and submicroscopic crystals of MOFs, such as those with the zeolitic-imidazolate framework (ZIF-8), are squeezed (Fig. 1); TEM images recorded frame-by-frame during compression allowed the researchers to build up a "movie" of the changes. They could thus see a dramatic shrinking of a MOF squeezed by a pressure of up to 4 GPa. They could also see changes in the structure-amorphiza-"Squeeze" cont'd. on page 84

"Squeeze" cont'd. from page 81

tion—and compaction of the pores within, which means the internal surface area plummets from around 1340 to just $253 \text{ m}^2/\text{g}$ at 1.9 GPa.

Utilizing the MR-CAT x-ray beamline 10-ID-B at the APS, powder x-ray diffraction studies were carried out on samples pressurized to 0.8 GPa, which showed that long-range order within the sample was not lost. Above this pressure, most of the peaks in the diffraction pattern were lost, implying that the crystal structure had been lost irreversibly and the material was now amorphous. Nevertheless, x-ray absorption spectroscopy on the zinc centers in the MOF structure revealed little change to the local geometry around these metal ions and only minor deviations when the pressure was increased. Of course, because ZIF-8 does not look the same in all directions (it is anisotropic), the way it responds to pressure depends on the direction of the force applied, which is taken into account in these studies.

When the pressure was released, the MOFs almost reverted to their original size and structure. But if the MOF was loaded with small molecules ("solvates"), such as methanol, applying even low pressure caused the microcrystals to shatter, even though pure ZIF-8 itself is well studied and known to be stable to such solvates.

This research thus reveals important clues as to how this type of MOF behaves under pressure with and without an organic payload of the kind that might be present when it is being used in gas storage, separation, or catalysis. — David Bradley

See: Zhi Su¹, Yu-Run Miao¹, Shi-Min Mao¹, Guang-Hui Zhang², Shen Dillon¹, Jeffrey T. Miller², and Kenneth S. Suslick^{1*}, "Compression-Induced Deformation of Individual Metal-Organic Framework Microcrystals," J. Am. Chem. Soc. **137**, 1750 (2015). DOI: 10.1021/ja5113436 *Author affiliations:* ¹University of Illinois at Urbana-Champaign, ²Argonne National Laboratory *Correspondence:* * ksuslick@illinois.edu

This research was supported by grants from the U.S. Navy (MURI N000141210828, K.S.S.), the

National Science Foundation (DMR 1206355, K.S.S.), the U.S. Department of Energy (DOE) Office of Science-Basic Energy Sciences (DEFG02-05ER46217, S.D.), and the University of Illinois at Urbana-Champaign Frederick Seitz Materials Research Laboratory Central Facilities. MR-CAT operations are supported by the Department of Energy and the MR-CAT member institutions. This research used resources of the Advanced Photon Source, a U.S. DOE Office of Science User Facility operated for the U.S. DOE Office of Science by Argonne National Laboratory under Contract No. DE-AC02-06CH11357.

10-ID-B • MR-CAT • Materials science, environmental science, chemistry • X-ray absorption fine structure, time-resolved x-ray absorption fine structure, micro x-ray absorption fine structure, microfluorescence (hard x-ray) • 4.3-27 keV, 4.3-32 keV, 15-90 keV • On-site • Accepting general users •